

CORRECTSIT™



DYNAMIC™



COMFORTMOVE



ERGO SOLEX™



CORRECTSIT™



Improve your posture and relieve your back
Back Quality Ergonomics:
Stools and chairs with a preventative character

BQE DUTCH DESIGN
BACK QUALITY ERGONOMICS
STOOLS & CHAIRS

All BQE work stools and chairs are designed in such a way that it is easy to adopt a better sitting posture while working, which gives the stools/chairs a clear preventative and curative character. Development and production are based on the general scientific background, specific studies and practical experience.

CORRECT SIT™



The **CorrectSit™** is a work stool which combines the triangular seat shape (as in the **Dynamic™** stool) with easy-to-operate adjustment options. This enables rapid changes of position and also allows alternation between several different users. The **CorrectSit™** is not weight-dependent; the seat and backrest can be adjusted separately.

Seat

The special triangular seat means that you are not forced to adopt a 90° sitting angle, but are given the space to adopt a position where the knees are lower than the hips. This 'open hip angle' makes it easier to stretch the back, so that it takes less effort to maintain a good work posture.

Backrest

The backrest is small and round, giving precise support in the lower back and ensuring maximum freedom of movement.

Tilting mechanism

The 'De luxe' and 'Basic' variant of the **CorrectSit™** has an adjustable tilting mechanism, which enables alternation between active and passive sitting.

Upholstery

The stool is upholstered in easy-to-clean, durable synthetic leather and is available in a wide range of colours and colour combinations.

Adjustment options

- Seat height from 44 - 91 cm (depending on the selected length of the gas cylinder)
- Tilt of the seat
- Depth of backrest (pressure of the support in the back)
- Height of backrest

Accessories

Armrest(s), foot ring, foot control.

Application

The **CorrectSit™** is ideal for a wide variety of professions, such as dentists and dental assistants, beauty specialists, teachers, therapists, nail stylists, laboratory personnel, hairdressers, etc. Many of these users are now enthusiastic about this stool. Thanks to its easy-to-operate adjustment, the **CorrectSit™** is also suitable for several different users in one workplace.

👁️ *For our instruction video check: www.BQErgonomics.com*